


Correct position



Foot pedal will not work


Wrong placement for microswitch

Wrong position

BRACKET

ARM

DOES NOT TOUCH (DURING FULL RANGE OF TRAVEL)



TWO MOUNTING SCREWS

NO SCREW (OPEN HOLE)

BIG SPRING

